



No.	Description	Part No.
1	Fuse	09486P-09
2	Fuse Holder	09487P-07
3	"O" Ring Washer (10/pk)	18900G-05
4	Knob	09347P-15
5	Shaft Seal Nut	13145P-34
6	Volume Control	09349P-30
7	Jack Cover (with Nut)	09518P-04
8	Neoprene Washer (10/pk)	18900G-39
9	Headset Jack	09228P-03
10	Push Button Cap	13056P-11

No.	Description	Part No.
11	Lightbulb	09493P-01
12	On/Off Switch (with bulb)	09851P-21
13	Mounting Kit	09865P-03
14	Grommet (4 ea.)	18900G-08
15	Connector (4 socket)	00084M-04
16	Screws and Nuts (4 ea.)	18900G-01
17	Cap (and nylon cord)	13238P-01
18	Gasket	13176P-03
19	Connector (2 Pin)	00084M-03
20	Box	26497P-03