



No.	Description	Part No.
1	Knob	09347P-15
2	Shaft Seal Nut	13145P-34
3	Volume Control	09349P-30
4	Gasket	13176P-03
5	Connector (6 Socket)	00084M-05
6	Screws and Nuts (4 ea.)	18900G-01
7	Cap (and nylon cord)	13238P-01
8	Connector (5 Socket)	00121M-01
9	Jack Cover (with Nut)	09518P-04
10	Neoprene Washer (10/pk)	18900G-39

No.	Description	Part No.
11	Headset Jack	09228P-03
12	Push-To-Talk Switch	09851P-28
13	Neoprene Washer (10/pk)	23100G-07
14	Guard, Push Button	26553P-01
15	Connector (4 socket)	00084M-04
16	Mounting Kit	09865P-03
17	Grommet (4 ea.)	18900G-08
18	Box	26497P-54
19	Flat Washer (10/pk)	23100G-08