



**PARTS LIST
MODEL U3812**


| No. | Description | Part No. |
|-----|----------------------|-----------|
| 1 | Shield, Switch | 17976P-01 |
| 2 | Guard, Switch | 26553P-03 |
| 3 | Push-To-Talk Switch | 26619P-12 |
| 4 | Connector (2 Pin) | 00084M-03 |
| 5 | Connector (4 socket) | 00084M-04 |
| 6 | Connector (6 Socket) | 00084M-05 |
| 7 | Gasket | 13176P-03 |

| No. | Description | Part No. |
|-----|-------------------------|-----------|
| 8 | Screws and Nuts (4 ea.) | 18900G-01 |
| 9 | Cap (and nylon cord) | 13238P-01 |
| 10 | Mounting Kit | 09865P-03 |
| 11 | Grommet (4 ea.) | 18900G-08 |
| 12 | Box | 26497P-12 |
| 13 | Push-To-Talk Switch | 26619P-01 |

ELECTRICAL SCHEMATIC MODEL U3812



189376-01 C