



No.	Description	Part No.
1	Knob	09347P-15
2	Shaft Seal Nut	13145P-34
3	Volume Control	09349P-30
4	Connector (4 socket)	00084M-04
5	Guard, Push Button	26553P-01
6	Neoprene Washer (10/pk)	23100G-07
7	Push-To-Talk Switch	09851P-28
8	Headset Jack	09228P-53
9	Jack Cover	15354P-01

No.	Description	Part No.
10	Connector (5 Socket)	00121M-01
11	Gasket	13176P-03
12	Screws and Nuts (4 ea.)	18900G-01
13	Cap (and nylon cord)	13238P-01
14	Connector (6 Socket)	00084M-05
15	Mounting Kit	09865P-03
16	Grommet (4 ea.)	18900G-08
17	Box	26497P-16
18	Flat Washer (10/pk)	23100G-08