



No.	Description	Part No.
1	Support Assembly	10370G-03
2	Spring Assembly	10117G-97
3	Dome, Right	15522P-08
4	Switch Cap Kit	41090G-13
5	Switch Guard	13148P-01
6	Push Button Switch	09851P-17
7	Dome Filter (1 each)	11410P-02
8	Earphone Assembly	10376G-29
9	Screws (10 pk)	00023M-09
10	Dome Filter (1 each)	25629P-05
11	Filter (1 each)	14096P-09
12	Earseal (pair)	18316G-02

No.	Description	Part No.
13	Overhead Cord Kit	22607G-06
14	Dome, Left (mic. side)	15522P-02
15	Nut and Washer Kit (10 pk)	12052G-02
16	Comm Cord Kit	18028G-75
17	Sleeve, Bend Relief	15333P-01
18	Connector, Electrical	09226P-02
19	Boom Attachment Kit	12840G-19
20	Kit, Boom Assembly w/Att.	41090G-12
21	M-77 Electret Mic	09168P-35
22	Mic Protector w/ O-Ring	40062G-02
23	Dome Filter (1 each)	15545P-01

ELECTRICAL SCHEMATIC
MODEL H4240

