



| No. | Description                | Part No.  |
|-----|----------------------------|-----------|
| 1   | Spring Assembly            | 40623G-30 |
| 2   | Dome, Right                | 15522P-33 |
| 3   | Adjustable Strap           | 10370G-03 |
| 4   | Overhead Cord Assembly     | 22607G-13 |
| 5   | Dome, Left (mic side)      | 15522P-36 |
| 6   | Nut and Washer Kit (10 pk) | 12052G-04 |
| 7   | Comm Cord Assy Kit         | 40599G-72 |
| 8   | Filter                     | 11410P-02 |
| 9   | Earphone Assembly          | 10376G-86 |
| 10  | Screw (10/pk)              | 00023M-07 |
| 11  | Filter                     | 25629P-05 |
| 12  | Dome Filter (1 each)       | 14096P-05 |

| No. | Description                  | Part No.  |
|-----|------------------------------|-----------|
| 13  | Filter ( 1 each)             | 14096P-09 |
| 14  | Undercut Gel Earseal (pair)  | 40863G-02 |
| 15  | Volume Control               | 09349P-40 |
| 16  | Switch Mic ON/OFF            | 26619P-21 |
| 17  | Boom Guide Kit               | 12840G-18 |
| 18  | Microphone Boom Assy         | 12765G-09 |
| 19  | Screen, Wind, Mic            | 15074P-08 |
| 20  | Windscreen Cover w/Tie       | 18792G-04 |
| 21  | PCB Assy, Mic AMP            | 40415G-54 |
| 22  | Mic Plug Cord Kit            | 40910G-06 |
| 23  | Mic Protector/Windscreen Kit | 41090G-23 |

# ELECTRICAL SCHEMATIC MODEL H9842BK

