






No.	Description	Part No.
1	Connector, Elec 7-Pin XLR	17195P-02
2	Toggle Switch, DPDT	09494P-38
3	Connector, Elec, 7-Socket XLR	17195P-03

No.	Description	Part No.
4	Bend Relief Sleeve	17836P-05
5	Case w/Clip	15380P-93
6	Guard, Push Button	26553P-01

ELECTRICAL SCHEMATIC
P/N 40937G-07



EXTERNAL PIN VIEW
7-PIN XLR



EXTERNAL SOCKET VIEW
7-SOCKET XLR

