

Digital Intercom System Model H9141 Headset-Mic, BTH

On land or at sea; for facilities or mobile platforms; in harsh, noisy environments or in quiet areas over long distances; for single or multi-channel communication; with wired security and wireless mobility, the Series 9100 Digital Intercom System provides communication clarity for the working world.

The H9141 is an behind-the-head, single-ear style noise-attenuating Headset, compatible with both U9110 wired Headset Station and U9110-BSW wireless Belt Station. It offers effective hearing protection with comfort, crisp communication without noise, and intuitive functionality with rugged, reliable construction.

As the immediate link between the user and the Digital Intercom System, the H9141 provides positive assurance that no critical communications are missed, and that safety and mission efficiency are greatly enhanced.



P/N: 40897G-11

| WHAT IT HAS | HOW IT HELPS |
|------------------------------|---|
| M-2H Advanced Noise- | Enhanced design with fine-tuned sound pressure level sensing |
| Cancelling Microphone | optimizes noise cancellation while increasing clarity with focus on |
| Integrated Microphone PTT | Positive-action momentary switch is located at the microphone |
| Switch | bracket; effortless to find and utilize in the most stressful of situations |
| Slotted Ear Dome | One side with earphone; opposite side empty with vented slots for |
| | hearing all ambient sound. |
| Premium Comfort Accessories | Adjustable overhead strap and undercut silicone/memory foam ear |
| | seals, designed for all-weather usability, improved attenuation and |
| | superlative comfort. |
| Coil Cord with Quick-Release | Allows rapid change-over between wired and wireless options for |
| Connector | mission flexibility; IP-68 connector assures connection integrity |

H9141 - Technical Data

| PHYSICAL | |
|--------------------|---|
| Weight | 14.7oz/417g |
| Communication Cord | 6 ft coil, with JAE connector (8-pin, JB5 series) |
| Certified NRR | N/A (single ear model) |
| Dome Type | Lightweight, ABS |
| Hardware | Stainless-steel; EM coat 6226 |
| Potentiometer | 220 ohm +/- 20% (1 each) |

| MICROPHONE | |
|--------------------|--|
| Microphone Type | M2H, Dynamic noise-cancelling |
| Boom Type | Hybrid wire/flex |
| Microphone Control | Momentary PTT (mic bracket) |
| Impedance | 150 ohm nominal |
| Sensitivity | 320uV nom., into 150 ohm load re: 94dB SPL 1/4" @ 1kHz |
| Frequency Response | 100Hz to 10kHz |
| Source Resistance | 150 ohm nominal |

| EARPHONE | |
|---------------------------|----------------------------------|
| Earphone type | Titanium Nitride driver (1 each) |
| Impedance | 35 ohm +/- 10% @ 1kHz |
| Sensitivity | 100 dB SPL/1mW @ 1kHz |
| Frequency Response | 20Hz to 20kHz |
| Total Harmonic Distortion | <0.3% nominal |

PROPER FIT

Proper fit of this device is critical to its noise attenuation effectiveness. Consult the instructions below for proper fit.

- 1. Open the headband adjustment all the way and put the hearing protector over your ears. Open the overhead support strap, disengaging the hookand-pile fasteners, and while supporting the weight, fit to your head until the ear cups achieve maximum attenuation and comfort, then engage the hook-and-pile fasteners on the overhead support straps in place.
- 2. The use of eyeglasses will reduce the attenuation afforded by this device. Use the thin temples on your glasses. Thin temples keep noise leakage at a minimum. Use "Stop Gaps", P/N 12500G-02; they are inexpensive and effective in restoring some of the attenuation which you would otherwise lose.

MAINTENANCE

In order for your hearing protector to perform properly, always comply with the following:

- 1. Never alter or modify your hearing protector. If you re-form the headband or muff, cut or punch holes in the ear seal, drill or punch holes in the ear cup or insert, or paint or coat the device, you will seriously jeopardize the hearing protector's performance and hearing damage could occur.
- 2. Seek repair or replacement of the hearing protector, immediately, if you see a defect, such as any sign of cracks or splits in cups, seals, or headbands.
- 3. Follow the manufacturer's recommendations for storage and cleaning. Storage in direct sunlight or at high temperatures, or cleaning in non-recommended cleaning solutions, may shorten the useful life of the hearing protector.
- 4. Each individual's body chemistry is different. Perspiration, body oils, and hair grooming cosmetics may effect the hearing protector materials; loss in elasticity or softness of ear cup seals and of the foam pads inside ear cups may result. Replace parts immediately, if these signs of wear occur.

CLEANING INSTRUCTIONS

- 1. Hearing protectors should be cleaned regularly using mild soap and water. Sponge off headpad and ear seals, taking care to rinse thoroughly.
- 2. Communication headsets should be cleaned in the same manner. Although this headset model is designed for marine environments, DO NOT UNNECESSARILY IMMERSE IN WATER. Most importantly, always wear your hearing protector in areas that have been identified as hazardous noise locations!



David Clark Company Incorporated

360 Franklin Street, Box 15054 Worcester, MA 01615-0054 Phone: 508-751-5800 Fax: 508-753-5827 www.davidclark.com

