

# **VOX BELT STATION**

U9913-BSW

**PURGING INSTRUCTIONS** 





First, <u>turn off</u> the Belt Station power by <u>pressing the power button</u> on the side of the unit





Next, <u>push</u> and <u>hold</u> the <u>PTT</u> <u>switch</u> on the front of the unit.



**PTT BUTTON** 





Then, <u>push</u> and <u>hold</u> the <u>power</u> <u>button</u>, powering the unit up, **while continuing to hold the PTT switch** 





To complete the process, when the LED indicator turns <u>red</u>, <u>release the power button...</u>



...then <u>release the PTT switch</u>. The LED indicator will <u>flash red</u> for 15 to 20 seconds, followed by a voice prompt, "Connection Deleted."

