


**PARTS LIST
MODEL U3410**


No.	Description	Part No.
1	Screw	09598P-99
2	Belt Hook	14885P-01
3	Spring Clamp	28355P-01
4	Headset Jack	09228P-03
5	Volume Control	14488P-02
6	Volume Control Knob	09347P-22
7	Switch	26612P-01
8	Spring	26608P-01

No.	Description	Part No.
9	Cap	26609P-01
10	Case	12972G-01
11	Printed Circuit Board	12059G-06
12	Circle Clamp 10/pk	24433P-11
13	Anti-Rotation Clip 10/pk	14176P-02
14	Grommet	14889P-04
15	Connector Kit	18352G-01
16	Cord	09271P-18HA000

ELECTRICAL SCHEMATIC
MODEL U3410

