



No.	Description	Part No.
1	Adjustable Strap	10370G-03
2	Spring Assembly	10117G-97
3	Dome, Right	15522P-03
4	Filter	11410P-02
5	Earphone Assembly	10376G-17
6	Screw (10/pk)	00023M-11
7	Filter	25629P-05
8	Undercut Gel Earseal (pair)	40863G-02
9	Overhead Cord Assembly	22607G-01
10	Nut and Washer Kit (10 pk)	12052G-02

No.	Description	Part No.
11	M-7A Electret Mic	09168P-33
12	Mic Protector w/ O-Ring	40062G-02
13	Comm Cord Assy Kit	18028G-09
14	Conn, Elec-Modified	14120P-05
15	Kit, Dome & Mic Boom	40688G-71
16	Left Dome (Detented Boom)	15522P-46
17	Left Dome (Nondetented Boom)	15522P-61
18	Boom Guide Kit (Detented)	12840G-09
19	Boom Guide Kit (Nondetented)	12840G-20
20	Hybrid Boom with Cord	18740G-05

ELECTRICAL SCHEMATIC
MODEL H3440

