



No.	Description	Part No.
1	Retaining Ring (10/pk)	00009M-03
2	Right Dome	15253P-47
3	Dome Filter	26475P-02
4	Screw (10/pk)	00023M-08
5	Earphone Assembly	10376G-86
6	Dome Filter	25629P-03
7	Dome Filter (1 each)	14096P-05
8	Filter (1 each)	14096P-09
9	Undercut Gel Earseal (pair)	40863G-02
10	Overhead Cord	18741G-19
11	Headband Spring	15671P-03
12	Headpad Assy	40075G-02

No.	Description	Part No.
13	Stirrup & Clamp Kit	22378G-19
14	Clip, Cord (4/pk)	15350P-02
15	Dome, Left	15253P-49
16	Boom Guide Kit	12840G-18
17	Microphone Boom Assy	12765G-09
18	Screen, Wind, Mic	15074P-08
19	Windscreen Cover w/Tie	18792G-04
20	Mic Plug Cord Kit	40910G-06
21	Comm Cord & Switch Assy	40895G-06
22	PCB Assy, Mic AMP	40415G-54
23	Volume Control	09349P-40
24	Mic Protector/Windscreen Kit	41090G-23

ELECTRICAL SCHEMATIC P/N 41049G-01



*
ROCKER SWITCH SHOWN IN PHN POSITION