



No.	Description	Part No.
1	Spring Assembly	40623G-58
2	Right Dome	11407P-94
3	Adjustable Strap	10370G-03
4	Left Dome (mic side)	11407P-51
5	Shield, Switch	17976P-01
6	Guard, Switch	26553P-03
7	Push-To-Talk Switch	14033P-01
8	Overhead Cord Assembly	22607G-01
9	Nut and Washer Kit (10 pk)	12052G-04
10	Communication Cord Assy Kit	41080G-12
11	Boom Attachment Kit	12840G-07

No.	Description	Part No.
12	Flex Boom Assembly	18812G-04
13	Microphone Plug Cord	18744G-01
14	M-77 Electret Mic	09168P-35
15	Filter	11410P-02
16	Earphone Assembly	10476G-02
17	Screw (10/pk)	00023M-08
18	Filter	25629P-05
19	Undercut Gel Earseal (pair)	40863G-02
20	Filter (1 each)	14096P-09
21	Mic Protector/Windscreen	41090G-05

ELECTRICAL SCHEMATIC P/N 40416G-53

