



**David Clark** COMPANY  
INCORPORATED

360 Franklin Street, Box 15054, Worcester, MA 01615-0054  
TEL. (508) 751-5800 E-Mail sales@DavidClark.com FAX: (508) 753-5827

## Throat Microphone Instructions for the H9842TM Headset

**TO CONNECT:** Line up prongs of plug from microphone with jack from headset. Push tightly together.

**TO DISCONNECT:** Pull apart plug from jack. Do not pull cords.

**PLACE** adjustable neck band around neck with microphone facing skin. Secure Velcro fastener so that microphone is in contact with skin, and tight enough to keep band from slipping.

**PLACEMENT** of microphone may vary for best transmission. While speaking and listening to the sidetone, start one inch from either side of center front of neck and move until transmission is clearest.

**CLEAN** neck band by removing microphone and washing in mild soapy water. Air dry and brush clean Velcro fastener.

